

iruCanal 取扱説明書

内容物

前輪側台座 (1)




前輪側台座
固定ボルト (1)



後輪側台座 (1)




泥除けウイング (2)




前輪側台座の取り付け

1. 台座をフォーククラウン裏側に押し込みます。
2. 台座のネジ穴とフォーククラウンのネジ穴の位置を揃え、固定ボルトをM4アーレンキーで締め込みます。



後輪側台座の取り付け


1. カプラーのピン固定ボルトをM5アーレンキーで取り外します（反時計回り）。
2. カプラー裏面に台座を取り付けます。
3. 裏からピン固定ボルトを締め込みます（時計回り）。



泥除けウイングの着脱

取り付け：ウイング根元のスリットを台座の突起に合わせて奥まで押し込みます。

取り外し：取り付けの手順と逆に引き抜きます。



iruCanal User's manual

Included items

Front bracket (1)




Front bracket
fixing bolt (1)



Rear bracket (1)




Mudguard wing (2)




How to attach the front bracket

1. Insert the bracket into the back of the fork crown.
2. Align the screw holes on both the bracket and the back of the fork crown and tighten the fixing bolt with an M4 hex wrench.



How to attach the rear bracket

1. Remove the pin-fixing bolt of the coupler with an M5 hex wrench (anti-clockwise).
2. Put the bracket onto the back of the coupler.
3. Co-tighten with the pin-fixing bolt (clockwise).



How to attach/detach the mudguard wings

Attach: Insert the wing along the rail on the bracket.

Detach: Pull the wing out from the bracket.

